


LABELMATE USA

Label Handling Innovations



AUTO-MATE Automatic Labeling Option (Eliminates the Need for the Footswitch)



The AUTO-MATE is an optional factory-installed accessory for all 900 and 1500 series BOTTLEMATES. The AUTO-MATE is installed on the Bottle Guide that abuts the bottom of the container and activates the unit automatically within 0.5 seconds when a container is placed on the rollers. Remove the container after it is labeled and repeat.

The Footswitch is still included with the unit, but is not necessary when using the AUTO-MATE. If at any time you would like to switch to using the Footswitch, simply unplug the AUTO-MATE.